



ProBook Audio Issue after Reimaging

SYMPTOM: Is your black student ProBook making a loud screeching noise when audio plays?

1. Right click on speaker icon and open "Sounds"



2. Click to open "Playback" tab. Click "Speakers" and click "Properties"



3. In the new window, click "Enhancements." Check "Disable all sound effects" and then click "OK."

